


VOXSON — Amplificatore stereo mod. H 302

RIGHT
RECHTS
DROIT
DESTRO


LEFT
LINKS
GAUCHE
SINISTRO




SWITCHES

COMMUTATEUR

S11 S21 : I
S12 S22 : I
S13 S23 : I
S14 S24 : I
S15 S25 : I
S16 S26 : I
S17 S27 : I
S18A S28A : I
S18B S28B : I





SWITCHES - UMSCHALTER
 COMMUTATEURS - COMMUTATORI
 S11 S21 : Magn-xtal
 S12 S22 : Input Selector
 S13 S23 : Loudness
 S14 S24 : Tape Monitor
 S15 S25 : Mono-Stere
 S16 S26 : High Filter
 S17 S27 : Low Filter
 S18A S28A)
 S18B S28B) OUTPUT SELECTOR

SYMBOLS SYMBOLES SIMBOLI	TR 101 TR 104 TR 105 TR 201	TR 102 TR 204 TR 205 TR 202	TR 103 TR 203	TR 106 TR 206 TR 107 TR 207	TR 108 TR 208 TR 109 TR 209	TR 110 TR 210	TR 111 TR 211 TR 112 TR 212	D100	D101 D102 D103 D105 D107	D201 D202 D203 D106 D108	D104 D204 D206
ALTERNATIVES ALTERNATIF ALTERNATIVE	BC 149 C		BF 246	BC 104/BC 147 BC 207	40595	40594	BU 104/ BOY 24 C	B 80/ C 3200	P 100		BA164/ BAY 71